



## Simple measurement of the glove size needed

Hold your hand out flat and measure the circumference of your hand above the base of the thumb with a tape measure as shown in the illustration on the left.

The measured value will give you an indication which glove size is suitable for you:

**Size S** = circumference 18 cm – 20.9 cm (7 inch – 8.2 inch)

**Size M** = circumference 21 cm – 23.9 cm (8.3 inch – 9.4 inch)

**Size L** = circumference 24 cm – 26.9 cm (9.5 inch – 10.6 inch)

**Size XL** = circumference 27 cm – 29 cm (10.7 inch – 11.4 inch)

In case of doubt pls. order the smaller size as **tipstim® glove** needs to fit tightly.



[www.tipstim.com](http://www.tipstim.com) · [www.bosana.de](http://www.bosana.de)